



Air Technologies Inc.

Silencer (PN: H250)

Silencer is designed to be used on:

ALL Velocity models

ALL SPU models

DFH

Installation:

Silencer is installed over the discharge grille of the unit

Silencer is equipped with adhesive velcro, peel off and install where required, the velcro will allow you the flexibility to turn the orientation in future

When installing, ensure that open end is directing air to the left or to the right, if directing air to the floor, ENSURE THAT THERE IS SPACE BETWEEN THE SILENCER AND THE FLOOR (DO NOT CHOKE THE DISCHARGE, MOTOR WILL OVER HEAT).



VELOCITY X1 or X2

- place Silencer on the outer frame of unit, Silencer must be removed if access to blower/motor is required

Velocity X4

- place Silencer on motor discharge door over the discharge grille, silencer does not require removal if access to motor is required



SPU (Stand-up Polisher)

- place Silencer over the discharge grille of the unit at the rear
- point the air discharge to the left or right
- if you point the air to the floor, ensure you have space between the silencer and the floor
(motor will overheat if you do not allow enough space)



DFH (Ductless Fume Hood)

- place Silencer on the top of the unit over the grille
- you can point the discharge to the front

QuatroO&M / H250-Silencer – 20160303

Engineers of Clean Air

30 Hymus Boulevard, Montreal, Quebec, Canada H9H 3L4

Tel.: (514) 630-4444

info@quatroair.com